



INVICTA

Movement Caliber PC32

INFO Battery: SR626SW (diameter 6.8mm x 2.6mm / Approx. 3 years)

Movement Caliber : PC32

Presentation

Display Elements

Minute Hand

Hour Hand

Second Hand

Date



Crown Positions:


1. Normal position
2. Quick correction of date
3. Setting of hour, minute, date

Movement Caliber : PC32

Setting

Setting the Time

- 1.1 Pull the crown to position 3.
- 1.2 Turn the crown to set hour/ minute hands to the desired time.
- 1.3 Push the crown back to position 1.



Movement Caliber : PC32

Setting

Setting the Date

- 2.1 Pull the crown to position 2.
- 2.2 Turn the crown clockwise step-by-step to the desired date
- 2.3 Push the crown back to position 1.

